



Sani-Kleen

Sanitizing Solution

DIRECTIONS FOR USE

RESTAURANTS & TAVERNS: After washing with dishwashing detergent and rinsing with clean water, immerse utensils in sanitizing solution prepared by adding 2.5 ounces of **Sani-Kleen** with 10 gallons of water to provide 200 ppm available chlorine by weight. Maintain contact with sanitizer for at least 2 minutes and allow sanitizer to drain. Do not rinse utensils with water after treatment. MACHINE DISHWASHING TERMINAL RINSE SANITATION: As a terminal sanitizing rinse for pre-cleaned food utensils, adjust automatic dispensing equipment to provide a sanitizing use solution of 100 to 200 ppm available chlorine by weight according to requirements of Public Health Authorities. Use solution should be tested frequently with a suitable chlorine test kit to ascertain that the rinsate strength does not fall below 50 ppm. In absence of a test kit a starting concentration of 200 ppm should be used. Do not rinse utensils with water after treatment.

TECHNICAL DATA

Color..... Yellow
 Scent..... Chlorine
 Foaming Low
 Solubility in Water Complete
 Density (lb/gal) 9.46
 Flash Point N/A
 pH 12.8





FEATURES & BENEFITS



PO Box 1990 | Largo, FL 33779

©Copyright 2007 Gator Chemical Company. All rights reserved.
Gator Chemical Company manufactures...